
READ BEFORE FIRST GRILL START!

Please be aware of the Alternate Start Up Method required to “Season” your new SweetHome Grill. The first start and possible starts when using other fuel types may require additional fuel to surpass the required 325F run temperature. Additional fuel (heat) is required to burn off oils and season the finish.

WARNING: Read operation manual and use as a reference to the following start up steps.

First Start Steps:

- 1) Add fuel to hopper per manual.
- 2) Plug grill into a grounded 115V receptacle.
- 3) Turn main switch “ON” (Located on back of hopper).
- 4) Press “Start/Stop” button on front control panel (Listen for pellets to fall into burn tray noted by a clinking sound).
- 5) Turn Main Power “OFF” (This primed the feed system).
- 6) Turn Main “ON”.
- 7) Press “Start/Stop” Allowing feed to run for about 20 seconds (This is the Added Feed Shot).
- 8) Turn Main Power “OFF”.
- 9) Turn Main Power “ON” and Push “Start/Stop” Button.

The grill will now complete a full start and run through 325F noted by (3) beeps from the control and “Control Dots” flashing. For seasoning operate grill for 30 to 45 minutes @ 400F.

To Turn Grill “OFF” press the “Start/Stop” Button for 3 seconds. Display - “CoL” for Cool Down. Refer to Owners Manual for additional information.

